




Installation Manual

MP5100.RI

Wall-mounted Lavatory Faucet Rough valve



1. Connection



2. Cut-Out Dimension

Finished Wall Must Be Between Min. & Max.

